

ENCORE CHIME DISPLAY - ASSEMBLY INSTRUCTIONS

Unpack the display and unwrap the dowels. Separate the dowels by length. You should find the following parts:

1 Base w/shelf	2 Shelves
1 Top	5 15 3/4-inch dowels with no knobs (A)
1 Wire grid	2 18-inch dowels (B)
4 Uprights (in 2nd box)	5 22-inch dowels (C)
1 Center frame (CF)	5 26-inch dowels (D)
1 Shelf frame (SF)	5 43-inch dowels (E)
1 Bag of hardware, including 8 bolts Allen wrench and 10 cup hooks	

With the base lying on its side, attach the four uprights using the bolts and Allen wrench provided (Fig. 1). It is important that the holes in the uprights are oriented as shown in the diagram. If they are facing the wrong direction, move that upright to an adjacent corner and fasten it there. You will also notice that there is a top, and there is a bottom. When fastened right-side-up, the first hole in the upright should measure 30 inches from the floor.

Next, attach the top to the four uprights using four more bolts. Make sure all bolts are tight so that there is no wobble in the uprights. Then, stand the display upright and set the base shelf in place.

Attach the center frame (CF) by inserting the two legs into the holes in the base (Fig. 2) and attaching the "arms" to the uprights using one of the shortest dowels (A). Next, attach the shelf frame (SF) to the top of the center frame and to all four uprights using three more of the same dowels.

The next step (Fig. 3) is to attach the rafters (R). Each one has one hole at one end and two holes at the opposite end. The one-hole end is the top. Each one also has one edge that has been predrilled for the cup hooks provided.

First, slide one of the 26-inch dowels (D) through the center hole of one side of the top piece. Then slide each rafter onto the dowel alternating the side that the cup-hook edge faces. When all six rafters are hanging from the dowel, slide the dowel through the other side of the top piece.

Spacing the rafters evenly apart, attach the bottom end of every other one to two of the uprights using the 26-inch dowels through the 2nd hole in the rafter. The cup hook holes should be on the bottom edge of the rafter. Now attach the other three in the same manner to the opposite end of the display.

Insert the rest of the dowels as shown.

Set the wire grid and two shelves in place (Fig. 4). Screw the cup hooks into the pre-drilled holes as desired.

