

Victorian Garden Gong (VGG)

Assembly Instructions

- 1) Unpack the Victorian Garden Gong. You should have the following components:
 - A) Gong Base
 - B) Gong and Upright
 - C) Mallet
 - D) Two Hex Bolts
- 2) Locate the mallet holder on the gong base; it is the small hole in one corner that accepts the end of the mallet handle. The front of the base will have the mallet holder on the right.
- 3) Position the upright and the base so the fronts are facing the same way, and align the bolt holes. (Hint: when aligned properly, the upright will be centered on the base.
- 4) To ensure a sturdy assembly, both bolts need to be tightened with a wrench.



Woodstock Percussion, Inc.
Shokan, NY 12481-5124
www.chimes.com
File # 1889INS031407

March 14, 2007
© 2007 WPI