


WOODSTOCK CHIME TREE DISPLAY™ ADAPTER (CTHA)
ASSEMBLY INSTRUCTIONS

Parts List

- 1 Spool
- 1 Washer
- 3 Product Hangers
- 3 UPC Holders

- 1) Determine how many Chime Tree Display Adapters you want to install on your Chime Tree Display. A Chime Tree Display that is 69 inches tall can be fitted with 1 or 2 adapters and one that is 85 inches can take up to 3. Each adapter is supplied with three product hangers. Please refer to your Chime Tree Display instructions for any questions concerning the display assembly or finished height.
- 2) Determine how high you want to display the retail boxes. Install the spool (1) and washer (2) between the two upright pieces (3 & 4) that are closest to that height. The spool must be slid onto the upright (4) above the washer. Thread the two uprights together. Note: If your display is already assembled you will have to first unscrew the two uprights where you plan to locate the adapter. Additional adapters can be installed between the remaining upright sections in a similar fashion.
- 3) Install the three product hangers and UPC/price label holders evenly spaced around the spool. Note: UPC clips are not included.



® Woodstock Percussion, Inc.
Shokan, NY 12481 USA
woodstock@chimes.com

12/14/07
©2007 WPI
File# 2069INS121407