

## Hanging Garden Bell Instructions

Since the Hanging Garden Bells are designed differently than standard wind chimes, they will not ring with the same frequency.

The following tips may help:

- \* Hang the garden bells directly from the string loop at the top of the chime. Don't add more string or the entire set may swing, rather than the individual bells.
- \* Hang the garden bells where the wind can reach them from as many directions as possible; an open corner on a building might be better than in a tree close to the trunk or branches.
- \*Experiment by hanging the garden bells at different heights. Wind velocity tends to increase at higher elevations.